

## **ICEFAB FABRIC INSTALLATION INSTRUCTIONS**



IF NEEDED, TRIM LOGO USING A PAIR OF SCISSORS.

LAY LOGO IN DESIRED LOCATION. IF LARGER LOGO WITH TILED PANELS LAYOUT ENTIRE LOGO FOR ALIGNMENT. THEN INSTALL FROM TOP TO BOTTOM BUTTING THE EDGES.

## DO NOT FLOOD AT THIS POINT. IT WILL CAUSE THE ICE LOGO TO FLOAT. ONLY USE SPRAYER AND ROLLER.

STARTING WITH THE FIRST PANEL PLACE SOMETHING IN THE MIDDLE OF THE PANEL TO HOLD IN PLACE. CLEAN PAINT BUCKETS OR PUCKS WORK WELL.

CAREFULLY ROLL THE RIGHT SIDE TO THE MIDDLE. THEN SPRAY A HEAVY COAT OF WATER USING THE SPRAYER/HUDDIE ON THE ICE SURFACE AND THE BACK OF THE FABRIC. ROLL OUT SLOWLY AND USE THE PAINT ROLLER TO CAREFULLY SMOOTH OUT.

SLOWLY WORK YOUR WAY SPRAYING WATER AND USING THE PAINT ROLLER TO REMOVE ANY AIR TRAPPED UNDER THE LOGO. DO NOT APPLY TO MUCH PRESSURE, YOU DO NOT WANT THE LOGO TO SHIFT.

REMOVE THE WEIGHTS FROM THE LOGO AND ROLL UP THE OTHER SIDE.

REPEAT THE ABOVE INSTRUCTIONS FOR THE OTHER SIDE.

IF NEEDED INSTALL TILED PANELS NOW BUTTING THE EDGES.

LET THE LOGO FREEZE GOOD THEN APPLY SEVERAL COATS OF MISTED WATER. LET FREEZE IN BETWEEN COATS.

MANY PRINT PROVIDERS CLAIM TO BE ABLE TO PROVIDE ICEFAB®

MESH AND FABRIC ICE LOGOS. WHY RISK AN INSTALL FAILURE

WHICH COULD END UP COSTING THOUSANDS OF DOLLARS TO

REPAIR. OUR MESH AND FABRIC ICE LOGOS ARE PROVEN TO WORK.

ONCE LOGO IS COMPLETELY FROZEN AND COVERED WITH A THICK COAT OF ICE, NORMAL FLOODING CAN BEGIN.

