

Cool C Wall

1. Slide swedged side of straight poles until push button clicks into place (match corresponding numbers) (fig. A).
2. Slide swedged side of curved pole into opposite curved pole until push button clicks into place (match corresponding numbers) (fig. A).
3. Screw upright poles onto curved poles using flathead screws (fig. A).
4. Slide graphic over stand (fig. B).

Applicable Products:

CC86	CC106	CC126
CC88	CC108	CC128
CC810	CC1010	CC1210

Note: number of sections for uprights and crossbars may vary depending on the Frame.

